

# **Century Components.**

## **Wall Filler Installation\***

\*Manufacturer Recommendation – Install filler to wall cabinet before cabinet is fastened to wall.

1) Align top & bottom of filler frame with top & bottom of adjacent cabinet.

2) Fasten filler to adjacent top cabinet:

- a) Slide filler to open position.
- b) Place 1 screw at bottom of filler frame & into cabinet wall.
- c) Place 1 screw at top of filler frame & into cabinet wall.
- d) Place 2 remaining screws – 1 at top & 1 at bottom of filler frame.

3) Install desired post or onlay to front of filler.

4) Install adjustable shelves at desired heights.